

How to Make Popcorn

Start- When pop is cold.

1. Turn KETTLE HEAT and KETTLE MOTOR switch on.
2. Make a test pop with 3 kernels of corn and ½ oz. of oil.
3. WAIT until kernels of popcorn in the kettle have stopped popping
4. Load pre-measured popcorn and oil pouch into kettle.
5. When corn has popped, DUMP KETTLE
6. Repeat cycle starting with Item #4; always pop 3-5 batches for best popcorn.

Care and Cleaning

*******Warning*******

Unplug your machine before cleaning glass panels and case. Never immerse the kettle, warmer, or any other part of this equipment in water, this will ruin the electrical components and automatically VOID the warranty.

Each time you finish a series of popping, wipe the outside of the kettle with a soft cloth to remove any oil drippage on the outside of the kettle. After you finish popping for the day, allow kettle to cool until it is not too hot to handle, but still warm. Unplug kettle and remove it from the machine. With a cloth, wipe out the inside of the kettle, kettle lid, crossbar, outside and underneath of the kettle.

Cleaning the cabinet of the machine is east. Take a clean cloth and wipe excess grease from the glass. Wipe the outside of the machine also.

NOTE: Never use a glass or plastic cleaner that contains **AMMONIA**. It will crack the plastic on the machine.